

Applicable Standards:

EN 837-1 Bourdon tube pressure gauges, dimensions, metrology, requirements and testing.

EN 837-2 Selection and installation recommendations for pressure gauges.

PZ72 Pressure gauges and gauge attachments 2014/68/

EC Pressure equipment directive

WARNING!

Before installation, be certain the appropriate gauge has been selected considering operating pressure/full scale pressure/proof pressure, wetted material requirements, media compatibility, operating temperature, vibration, pulsation, desired accuracy and any other gauge component related to the service application (including the potential need for protective attachments and/or special installation requirements). Failure to do so could result in equipment damage, gauge failure and/or personal injury. Only qualified personnel should be permitted to install and maintain pressure gauges.

2. INSTALLATION

When installing the gauge connection into the application,

use the wrench area (above the threaded portion)

to thread in and tighten the gauge. Do not use the gauge case to install the gauge. This could result in loss of accuracy,

excessive friction, or mechanical damage to the pressure element or gauge case.

The gauge connection must be compatible with the mating

connection and must be assembled appropriately. If the mating parts do not seal completely, a sealing material may be considered.



P-LBXX

After installation, pull up the Black cap on the fill/vent plug to the full open position. Opening the vent plug will relieve internal pressure changes in the gauge case that otherwise would have been induced by environmental changes in pressure and/or temperature. Without being vented this change in internal pressure could adversely affect the accuracy of the gauge. If liquid filled, only open vent plugs when the plug is oriented in the vertical position.

3. STORAGE

Gauge should remain in original packaging until installation. This will protect from mechanical damage as well as environmental conditions. Storage temperature range from -40 °F to 158 °F (-40 °C to 70 °C).

4. MAINTENANCE/REPAIRS

Check regularly to ensure the gauge is in good working order. When removing the gauge from the application make sure there is no pressure in the system and all system media has been isolated from the gauge. If gauge is damaged or out of calibration a new gauge must be installed.

These gauges are not to be re-calibrated.

Misuse or misapplication of this gauge could result in gauge failure, equipment damage and/or personal injury

